

HD Digital Satellite Receiver
Récepteur satellite numérique HD

الرياضية



User's Manual Manuel de l'utilisateur

HD-FREE

The default password is 0000.
Le mot de passe par défaut est 0000.

MANUAL/HDFREE/100GBRFAAR



20000-00372



www.humaxdigital.com

HUMAX



Notice




Notice

Thank you for purchasing a HUMAX product. Please read this user’s manual carefully to be able to safely install, use and maintain the product at maximum performance. Keep this user’s manual next to your product for future reference. The information in this user’s manual is subject to change without notice.

Copyright (Copyright © 2012 HUMAX Corporation)

Not to be copied, used or translated in part or whole without HUMAX’s prior consent in writing except approval of ownership of copyright and copyright law.

Meaning of Symbols

	To reduce the risk of electric shock, do not remove cover (or back). No user serviceable parts inside. Refer servicing to qualified service personnel.
	This symbol indicates dangerous voltage inside the product that presents a risk of electric shock or personal injury.
	This symbol indicates important instructions accompanying the product.

Warnings, Cautions and Notes

Throughout the whole manual, pay special attention to the following marks that indicate hazardous situations.

Warning

Indicates a hazardous situation which could result in serious injury

Caution

Indicates a situation which could damage the equipment or other apparatus

Note

Indicates additional information to make the user aware of possible problems and information of any importance to help understand, use and maintain the installation.

Warranty

The warranty does not cover parts which may become defective due to misuse of the information contained in this manual.

‘WEEE’ Instructions

This product should not be disposed with other household wastes at the end of its working life. Please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. This will prevent possible harm to the environment or human health from uncontrolled waste disposal.

Domestic users:

Please contact either the retailer where you purchased this product or their local government office for details of where and how they can take this item for environmentally safe recycling.

Business users:

Contact your supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Trademarks

- Irdeto is a trademark of Irdeto Access B.V.

For Your Safety

Safety Instructions

1. POWER SUPPLY

- Operate this product only from the type of power supply shown on the marking label. If you do not know the type of power supplied to your home, contact your local power company.
- Disconnect the power supply before you start any maintenance or installation procedures.

2. OVERLOADING

- Make sure that the wall outlet, extension cord and adapter have a sufficient power rating for the appliance. If not, this can cause an electric fire shock.

3. LIQUID

- Do not expose this product to liquids. Do not put objects filled with liquid on the product.

4. CLEANING

- Disconnect the product from the wall outlet before you clean it.
- Use a moist cloth to clean the product. Do not use solvents. Wipe the surface gently with a soft cloth as it may get scratched.

5. VENTILATION

- Make sure that the slots on top of the product are not blocked. It is necessary to have a sufficient airflow into the unit.
- Do not put electronic equipment on the product.
- Do not put objects on the product. This will block the ventilation or cause damage to the surface.

6. ATTACHMENTS

- Do not use any unsupported attachments as these may be hazardous or cause damage to the product.

7. LIGHTNING, STORM OR NOT IN USE

- Unplug the product from the wall outlet and disconnect the antenna during a thunderstorm or when left unattended and unused for long

periods of time. This will prevent damage to the unit due to lightning and power-surges.

8. EXTRANEIOUS OBJECTS

- Do not insert anything through the openings in the unit, where they can touch dangerous voltage points or damage parts.

9. REPLACEMENT OF PARTS

- When replacement of parts is required, be sure the service technician uses replacement parts specified by the manufacturer or those that have the same characteristics as the original part. Unauthorised substitution may result in additional damage to the unit.

10. CONNECTION TO THE SATELLITE DISH LNB/CABLE TV SIGNAL/AERIAL

- Disconnect the power supply before you connect or disconnect the cable from the satellite dish/cable TV signal/aerial. If not, this can cause damage to the LNB/cable TV line/aerial.

11. CONNECTION TO THE TV

- Disconnect the power supply before you connect or disconnect the cable from the TV. If not, this can cause damage to the TV.

12. EARTHING (satellite only)

- Earth the LNB cable to the system earth for the satellite dish.

13. LOCATION

- Place the product indoors to avoid exposure to lightning, rain or sun. Do not place it near a radiator or heat register.
- Keep at least 10 cm clearance from any other appliances susceptible to electromagnetic influences such as a TV or a VCR.
- If you place the product on a rack or a bookcase, make sure that there is adequate ventilation and that you have followed the manufacturer's instructions for mounting.
- Do not place the product on an unstable surface where it can fall. A falling product can

cause serious injury to a personnel and serious damage to the appliance.

Cautions and Warnings

1. To avoid damage of the power cord or plug

- Do not modify or process the power cord or plug arbitrarily.
- Do not bend or twist the power cord.
- Make sure to disconnect the power cord while you hold the plug.
- Keep heating appliances as far as possible from the power cord to prevent the cover vinyl from melting.
- The mains plug, as a disconnection device, shall remain readily accessible by the user.

2. To avoid electrical shock

- Do not open the main body.
- Do not insert metal or inflammable objects inside the product.
- Do not touch the power plug with wet hands.
- Disconnect the power cord in case of lightning.
- Unplug the power cable before you install the antenna cable.

3. To avoid damage of product

- Do not use the product when it is out of order. If you continue to use the product when defective, this may cause serious damage. Make sure to contact the customer service centre if the product is out of order.
- Do not insert metal or alien substance into the slots for the modules or Smartcards. It may cause damage to the product and reduce its life span.

4. To avoid damage of the hard disk drive (PVR only)

- Do not move the product or turn the power off suddenly while the hard disk drive is running.
- The company shall not be liable for any corruption of data on the hard disk drive caused by carelessness or misuse of the user.

Contents

Notice	1
For Your Safety	2
Contents & Accessories	3
Contents	
Accessories	
Quick Start Guide	4
Front & Rear	
Remote Control	
Connections	
Wizard	
Managing Channels	8
Channel List	
Edit Channels	
TV Guide.....	12
Preferences	13
Installation	14
Search Channels [Fixed Antenna]	
Search Channels [SCD Antenna]	
Search Channels [Motor Antenna]	


Software Update (OTA)
Factory Default

System	18
---------------------	-----------

Appendix.....	19
----------------------	-----------

Specification
Trouble Shooting
HUMAX Customer Support
Error Messages
Glossary
Open Source Software Notice
Warranty Certificate

Accessories



Remote Control
/ Batteries



User's Manual



HDMI Cable




AC Adaptor

Note: These accessories may vary according to area.

Quick Start Guide


Front & Rear

Note: The image may differ from the actual product.




Inserting the Smartcard

1. Hold the Smartcard horizontally with the electronic chip facing downwards.
2. Insert the Smartcard into the slot.



Remote Control




	MUTE	Mutes audio
	WIDE	Sets the display format
	STANDBY	Switches between operation and standby modes
	SUB	Changes the subtitle language
	AUDIO	Changes the audio language
	TEXT	Enters the digital text service
1	Playback Control Buttons	Slow, Record, Rewind, Fast Forward, Play/Pause, Stop, Instant Replay, Skip (Reserved for future functionality)
	LIST	Displays the channel list
	MEDIA	Displays the media list (Reserved for future functionality)
	GUIDE	Displays the programme guide
	EXIT	Exits all On-Screen Display (OSD) screens
	BACK	Returns to the previous channel or the previous screen
	OK	Selects a menu or confirms
	ARROW Buttons	Moves the cursor up, down, left or right
		Changes the audio volume
		Changes the channel or page

	i (Information)	Displays the channel and programme information
	OPT+	Displays the channel attributes
2	COLOUR Buttons	For interactive applications
	NUMERIC	(0-9)
	TV/RADIO	Switches between TV and radio modes
	MENU	Displays the main menu

Inserting Batteries

Insert the batteries matching the plus(+) and minus(-) at each end.




Connections

This section describes how to connect your product to match your particular devices and to gain optimum signal quality.

Warning: Connect all devices before you plug any power cords into the wall outlet. Always turn off the product, TV and other devices before you connect or disconnect any cables.

Note: If you encounter any problems setting up your product, please contact your local retailer or HUMAX Customer Service.



Connecting the Antenna

Connect the aerial to the **LNB IN**.

Connecting the TV

2-1 Using an HDMI cable

For the best picture quality, use an HDMI cable to connect to the TV.

2-2 Using an RCA cable

For good picture quality, use an RCA cable to connect to the TV.

Powering On

1. Connect the power cord of the product to a wall outlet.
2. Power on by pressing the **STANDBY** button on the remote control or the **STANDBY** button at the front panel.

Wizard

The installation wizard operates automatically when you power on the product for the first time or do factory default in menu.

Note: If you exit the installation wizard without fully completing the channel searching procedure, you may not have all of the channels available. In this case, go to **MENU > Settings > Installation** and search for more channels.

1. Language

Select the appropriate language from the list.

2. Display

Set the video output to your TV.

3. GMT Offset

Select your country to determine the time zone.

4. Search Channels

- **Automatic Search:** Search all channels of NILESAT(7.0W) and BADR(26.0E) and HOT BIRD(13.0E) automatically.
- **Skip:** If you have SCD or motor antenna, skip the search process and go to **MENU > Settings > Installation**.

5. Automatic Search


Channel search will begin automatically.
Save the found channels when the search is complete.




6. Result

The result of the installation wizard will show. Select **Finish** to exit the wizard.





Programme Information (i-Plate)

The i-plate is an information banner that is displayed for a few seconds whenever you change channels. Press the **i** button while you watch a programme to display the i-plate. Press the **EXIT** button to hide it.



	Viewing detailed programme information Press the i button again while the i-plate is displayed.
	Viewing Previous/next programme information Press the ◀▶ button while the i-plate is displayed.
	Viewing Programme information of other channels Press the ▲▼ button while the i-plate is displayed. Press the OK button to change to the selected channel.

Icons

	Locked Programme
	Scrambled Programme
	Parental level
	HD Programme
	Scheduled programme
	Resolution
	Subtitle
	Teletext
	Screen ratio

Managing Channels

Channel List

You can access the channel list in several ways.

- Press the **LIST** button.
- Press the **MENU** button and select **Channel List**.

Changing Channels

Select the channel you want to watch and press the **OK** button. The channel will change.



Changing Group

Press the **►** button to display the list of the selected channel group. (TV, HDTV, A-Z, Radio, Favourite 1~5, Recent)



RED

Sorting Channels

Press the **RED** button to sort the channels in numerical or alphabetical order.



GREEN

Filtering Channels

Press the **GREEN** button to filter the channels according to channel type in TV or Radio list. (Satellite, Pay Channel, All)

Note:

- : Locked channel, : Scrambled channel (CAS icons)
- Press the **i** button to view the detailed channel information.
- Press the **LIST** or **EXIT** button to exit.
- Press the **TV/RADIO** button to switch between **TV** and **Radio** groups.

Editing Channels in Channel List

Select a channel you want to edit and press the **YELLOW** button.

Favourite

Setting Favourite Channels

Select a favourite group you want to move the channel to and press the **OK** button.

To remove a channel from a favourite group, select the group and press the **OK** button again.

Lock

Locking Channels

Select **On** or **Off**.

Note:


- The default password is 0000. If you have forgotten your password, please contact your local distributor.
- To edit multiple channels, go to **MENU > Settings > Edit Channels**.

Edit Channels

Editing Channel List

MENU > Settings > Edit Channels > Edit Channel List

Edit Channel List will help you delete, move, lock or rename multiple channels.



Note:

- : Locked channel, : Scrambled channel (CAS icons)
- Press the **i** button to view the detailed channel information.
- Press the **TV/RADIO** button to switch between **TV** and **Radio** groups.
- Press the **MENU** or **EXIT** button to exit. Press the **BACK** button to return to the previous screen.
- The channels that are automatically numbered by the broadcaster cannot be deleted or moved.


	Deleting Channels Select the channels using the ▲/▼ and OK button and press the RED button.
	Moving Channels Select the channels using the ▲/▼ and OK button and press the GREEN button. Move the selected channels to the location you want using the ▲/▼ and OK button.
	Changing Group To list the channels of other groups, press the YELLOW button and select a group you want.
	Changing Background You can change the channel displayed in the background while editing. Select the channel you want to watch and press the BLUE button.
	Locking / Unlocking Channels Renaming Channels Selecting / Releasing All Channels

Managing Channels

Editing Favourite List

MENU > Settings > Edit Channels > Edit Favourite List

Edit Favourite List will help you add or remove channels from the favourite groups.



Note:


- : Locked channel, : Scrambled channel (CAS icons)
- Press the **i** button to view the detailed channel information.
- Press the **TV/RADIO** button to switch between **TV** and **Radio** groups.
- Press the **MENU** or **EXIT** button to exit. Press the **BACK** button to return to the previous screen.
- The channels that are automatically numbered by the broadcaster cannot be deleted or moved.

	<p>Adding Favourite Channels Select the channels to add using the ▲/▼ and OK button in the left column and then press the RED button. The added channels will be listed in the right column.</p> <p>Removing Favourite Channels Select the channels to remove from the right column using the ▲/▼ and OK button and then press the RED button.</p>
	<p>Changing Group To list the channels of other groups in the left column, press the GREEN button and select a group you want. (TV, Radio, HDTV)</p> <p>Moving Favourite Channels Select the channels using the ▲/▼ and OK button in the right column and then press the GREEN button.</p>
	<p>Changing Favourite Group To list the channels of other favourite groups, press the YELLOW button and select a group you want.</p>
	<p>Changing Background You can change the channel displayed in the background while editing. Select the channel you want to watch and the press the BLUE button. The background channel will change.</p>
	<p>Locking / Unlocking Channels Renaming Channels Selecting / Releasing All Channels</p>

TV Guide

You can access the TV guide in several ways.

- Press the **GUIDE** button.
- Press the **MENU** button and select **TV Guide**.



Note:

- Press the **i** button to view the detailed programme information.
- **L** : Scheduled programme

Watching Programmes

1. Select a programme and press the **OK** button. The programme will display in the preview.
2. Press the **OK** button again to exit the TV guide and watch the programme.

Setting Reminders

1. Select a future programme and press the **OK** button.
 2. Press the **OK** button again to cancel the reservation.
- The reserved programmes will be added automatically to **Schedule**.

Finding Programmes

To find the programmes specifically according to the keyword or genre, press the **GREEN** button.


Scheduling Reminders

To schedule the reminders, press the **YELLOW** button.

Changing Group

To list the channels of other groups, press the **BLUE** button and select a group you want.

Preferences



Parental Control

- **Maturity Rating:** You can block the programme if the programme is above the age limit.
- **Change STB Password:** Enter a new password.

Note:

- The default password is 0000. If you have forgotten your password, please contact your local distributor.
- Enter the password to view the blocked programmes.

Language Setting

You can set the system language, audio language or subtitle language.

Setting Power On/Off Timer

You can set the time the receiver powers on or powers off.

Video Setting

- **Screen Ratio:** You can select the screen ratio of your TV.
- **Resolution:** You can set the resolution of the screen.
- **Display Format:** You can select the display format according to the screen ratio of your TV.
- **Letterbox & Pillarbox Colour:** You can select the colour of the margin space in Letterbox or Pillarbox mode.

Audio Setting

- **Digital Audio Output:** You can select the digital audio signal output.
- **Lip-Sync:** You can adjust the sound difference between audio and video.

Screen Display

- **Info Display Time:** You can set the duration the i-plate is displayed whenever you change the channel.
- **Transparency:** You can set the transparency of the On-Screen Display.
- **Subtitle Font:** You can set the subtitle font.

Search Channels [Fixed Antenna]

Installation allows you to configure your antenna and search the TV and radio channels.

MENU > Settings > Installation


- 1 Press the **RED** button and select **Fixed Antenna**.
Select **OK** to save and exit.
- 2 Select **Search Channels** and press the **OK** button.
Select **Switch Type** and select **LNB Only** or **DiSEqC**.
- 3 Select a satellite figure and press the **OK** button.
 - **Satellite**: Select the satellite.
 - **LNB Frequency**: Select the LNB frequency.
 - **22kHz Tone**: Select the DiSEqC switch.
 - **DiSEqC**: Select the DiSEqC switch.
 - **Test Transponder**: Check the signal status of each transponder and select the one with the best quality.
Select **OK**.

Note: When **Switch Type** is set to **DiSEqC**, both **22kHz Tone** and **DiSEqC** are activated.

- 4 Select **Transponder** under the activated satellite figure and press the **OK** button.
Select a value in the transponder list.
- 5 Select **Search** and press the **OK** button. The found channels will be listed.
- 6 When the search is completed, select **Save** and press the **OK** button.

Note:

- Select **User Define** to enter the options directly.
- All channels will be deleted if you change the antenna type.
- The default password is 0000. If you have forgotten your password, please contact your local distributor.



Search Channels [SCD Antenna]

Single Cable Distribution enables the delivery of broadcast programming over a single cable to multiple users eliminating the numerous cables required to support other electronics devices.


If you are using more than one satellite receiver, set one receiver at a time and turn off the others while setting. Refer to the satellite antenna manual for details.

 **MENU** > Settings > Installation

- 1 Press the **RED** button and select **SCD Antenna**. Select **OK** to save and exit.
- 2 Select **Search Channels** and press the **OK** button.
- 3 Select **SCD Setting** and press the **OK** button to set the channel(band) and frequency for this receiver.
 - **Tuner1**: Select from Channel 1~8.
 - **Frequency**: The frequency is set based on the channel of tuner1. Select **OK**.
- 4 Select a satellite figure and press the **OK** button.
 - **Satellite**: Select the satellite.
 - **LNB Frequency**: Select the LNB frequency.
 - **Test Transponder**: Check the signal status of each transponder and select the one with the best quality. Select **OK**.
- 5 Select **Transponder** under the activated satellite figure and press the **OK** button. Select a value in the transponder list.
- 6 Repeat the two steps above to set more satellites.
- 7 Select **Search** and press the **OK** button. The found channels will be listed.
- 8 When the search is completed, select **Save** and press the **OK** button.

Note:

- Select **User Define** to enter the options directly.
- Select **Stop** and press the **OK** button to stop the channel search.
- All channels will be deleted if you change the antenna type.
- The default password is 0000. If you have forgotten your password, please contact your local distributor.



Search Channels [Motor Antenna]

You can set the position of the satellites when you use a motor antenna for efficient channel search.

MENU > Settings > Installation

- 1 Press the **RED** button and select **Motor Antenna**. Select **OK** to save and exit.
- 2 Select **Search Channels** and press the **OK** button.
- 3 Select **Motor Setting** and press the **OK** button to set the motor type and location.
 - **Motor Type:**
 - DiSEqC1.2:** General motor antenna using DiSEqC 1.2.
 - USALS:** Motor antenna using USALS.
 - **My Longitude:** Enter the longitude and direction.
 - **My Latitude:** Enter the latitude and direction.
 - **LNB Frequency:** Enter the LNB frequency.


Select **OK**.



Note: When **Motor Type** is set to **DiSEqC 1.2**, both **My Longitude** and **My Latitude** are inactivated.

- 4 Select **Edit Satellite Data** and press the **OK** button to select the satellites that the motor antenna is pointing to. Select satellites using the **▲/▼** and **OK** button. When selecting **User Define**, enter the **Longitude** and **Direction**. Press the **BACK** button to save and return.
- 5 Select **Position Setting** and press the **OK** button to set the antenna position for the selected satellites.
 - **Satellite:** Select the satellite.
 - **Transponder:** Select the transponder.
 - **Motor Driving: Continuous – Step - Time**
 - **Driving Size:** When motor driving is set to **Step** or **Time**, select one from 1~127.
 - **Go to Stored Position:** Make the antenna turn toward the position of the selected satellite. Fine-tune the position using the **◀/▶** button until the signal strength and quality reach the maximum level.
 - **Store Current Position:** Save the adjusted position.
 - **Recalculate:** Recalculates the positions of all satellites based on the position of current satellite.

Press the **BACK** button to save and return.

Note: When **Motor Type** is set to **USALS**, **Motor Driving**, **Store Current Position** and **Recalculate** are inactivated.





6 Select **Limit Setting** and press the **OK** button to set the operation limit of the motor.

- **Limit Position:** Select **East** or **West**.
- **Set Limit:** Set the operation limit to **East** or **West** using the ◀▶ button.
- **Reset Position:** Initialise the position of the motor antenna to the factory default. Press the **BACK** button to save and return.

7 Select a satellite you want to search.

8 Select **Transponder** under the activated satellite figure and press the **OK** button. Select a value in the transponder list.

9 Select **Search** and press the **OK** button. The found channels will be listed.

10 When the search is completed, select **Save** and press the **OK** button.

Note:

- When you use a motor antenna, only the channels of one satellite can be searched.
- Repeat the search process to search more satellites.
- Select **Stop** and press the **OK** button to stop the channel search.
- All channels will be deleted if you change the antenna type.
- The default password is 0000. If you have forgotten your password, please contact your local distributor.

Software Update

MENU > Settings > Installation > Software update

Automatic Update

1. Select **Automatic Update**.
2. When new software is detected, select **Yes** to start the update process.

Manual Update

1. Select **Manual Update**.
2. Enter the search options.
2. Select **Search** and press the **OK** button to search for new software.
2. When new software is detected, select **Yes** to start the update process now.

Note:

- It may take 5~10 minutes to update the software.
- When the software update is completed, the product is automatically powered off and on again.

Factory Default

MENU > Settings > Installation


1. Select **Factory Default**.
2. A popup will appear. Select **Yes**.
3. You will be prompted to enter the password. Enter the password.

Note:

- The default password is 0000. If you have forgotten your password, please contact your local distributor.

Warning: Note that once you perform factory default, all user configured data will be reset. Shortly after you complete the factory default, the installation wizard will appear automatically.

System



System Information

You can view the system information.

Signal Detection

You can check the signal strength and quality of the searched channels.

IRDETO Software Update

You can update the software when available.

Conditional Access

You can view the Smartcard information.

Mail Messages

You can check the mail messages.

Specification

Tuner & Channel	
No. of Tuners	1
Input Connector	F-Type, IEC 169-24, Female
Frequency Range	950 MHz to 2150 MHz
Signal Level	-25 to -69dBm
LNB Power & Polarisation	Vertical : +13.5 V (+14.5 V at high voltage) Horizontal : +18 V (+18.5 V at high voltage) Current : Max. 500 mA (Overload protection)
22kHz Tone	Frequency : 22 ± 4 KHz Amplitude : 0.7 ± 0.2 V
DiSEqC Control	Version1.0, 1.2, USALS, SCD (Single Cable Distribution)
Demodulation	QPSK, 8PSK
Input Symbol Rate	DVB-S : 2-45MBaud DVB-S2: 3~42MBaud(QPSK), 3~30MBaud(8PSK)
FEC Mode	DVB-S: Auto,1/2,2/3,3/4,5/6,7/8 DVB-S2: Auto,1/2,3/5,2/3,4/5,5/6,8/9,9/10 (QPSK) Auto,3/5,2/3,3/4,5/6,8/9,9/10 (8PSK)
MPEG Transport Stream A/V Decoding	
Transport Stream	MPEG-2 ISO/IEC 13818 Transport Stream Specification
Profile Level	MPEG-2MP@ML, MPEG-2MP@HL, MPEG-4 HP@L4 .1
Input Rate	15MB/s Max
Video Format	4:3, 16:9
Video Resolution	1080p, 1080i, 720p, 576p, 576i
Audio Decoding	MPEG/MusiCam Layer I & II, AC3 downmix
Audio Mode	Single channel/Dual channel/Joint stereo/Stereo

Memory	
Flash Memory	128MB
RAM	256MB
Audio/Video/Data In/Out	
Video	RCA-Type(CVBS), HDMI/HDCEP
Audio	Audio L/R
Power Supply	
Input Voltage	100-240V a.c., 50/60Hz
Type	Adaptor
Power Consumption	12Vd.c. / 2A
Protection	Separate internal fuse. The input should be protected against lightning.
Physical Specification	
Size	200x33x155(mm)
Weight (Net)	485g
Operating Temp	0 °C to +45 °C
Storage Humidity	-10 °C to +70 °C

Note: The specifications are subject to change without notice.

Trouble Shooting

Before contacting the customer service centre, make sure to read the tips below carefully. If the problem persists after you complete the following procedure, please contact HUMAX customer service for further instructions.

1. No message is displayed on the front display. (The product will not switch on.)

- Check the main power cable and make sure it is plugged into a suitable power outlet.
- Check that the mains supply is switched on.
- Connect the power cable to a different power outlet.
- Check that the power switch is on at the rear of the product. (where applicable)

2. No picture

- Make sure that the product is powered on and in operation mode. (Press the STANDBY button)
- Make sure that the AV cable is firmly connected to the TV.
- Make sure that the antenna cable is properly connected to the product.
- Be sure to activate channel search.
- Check the brightness level of the TV.
- Check if the channel is currently on air.
- Make sure that STB or PVR is selected as input on the remote control.
- Make sure that the antenna setting in the menu is correct. (satellite only)

3. Poor picture/sound quality

- Make sure there is no mobile phone or microwave oven near the product.
- Keep the power cable and the RF cable apart from each other.

Note: If the antenna is covered with snow or the RF is weakened by heavy rain, the condition of the sound and picture may temporarily be poor. However, poor sound and picture quality due to weather conditions cannot be accepted as a malfunction of product.

[Satellite]

- Change the satellite dish for a larger one as this will increase the signal levels received.
- Replace the LNB with a lower noise factor in cases where the noise factor is too high.
- Replace the LNB with a lower noise factor in case the noise factor is too high.

- Replace the LNB with a new one in case it is damaged or out of order.
- Install the antenna in an obstacle-free place.
- Check the signal levels and adjust your antenna if the level is too low. The signal level may be affected by weather conditions.

[Terrestrial]

- Adjust the antenna direction to get a better picture.
- Set the antenna power in menu to On, if you use the active antenna to improve the reception. (where applicable)

4. No or poor sound

- Check that your AV cable is connected correctly.
- Check the volume levels of your TV set and the product.
- Check if the product or TV is on mute.
- Check audio type or soundtrack option. (where applicable)

5. Remote control does not operate.

- To control the product, the top end of the remote control should point directly towards the receiving part of the product.
- Remove and reinsert the batteries in the remote control.
- Replace the batteries in the remote control for a new set.
- Set the remote control to STB or PVR mode, if you are using the universal remote control. (where applicable)

6. Cannot make reservations.

- Check that no previous reservations are conflicting with the new reservation.

7. No password information is given.

- The default password is 0000.

8. Channel search does not work.

- **[Satellite]** Make sure that the antenna setting in the menu is correct.
- **[Cable]** Make sure that your cable is connected correctly.
- **[Terrestrial]** Use the appropriate antenna capable of receiving VHF or UHF channels for your area.

9. Cannot update new software.

- If the product does not show a message requesting update, this means no software is available.

Appendix

10. Cannot watch scrambled channels.

- Check that you have the appropriate Smartcard or CI-Module. Reinsert the Smartcard or CI-Module and make sure it initialises correctly.
- Check in the menu that the product is detecting the Smartcard or CI-Module.
- Check in the menu that you have a valid subscription to the channels you want to view.
- Make sure that the Smartcard or CI-Module is not damaged.

11. Cannot watch pay channels.

- Check in the menu that you have a valid and working subscription to the channels you wish to view.

12. The product makes a humming noise.

- The noise is from the fan; the hard disk is operating normally.

13. Cannot record programmes. (PVR only)

- The hard disk is full. Delete unnecessary programmes and make space for new recording.
- Check if the recording conflicts with another channel. Stop the current recording or wait until the recording is finished.
- Check that the product is switched on when the recording starts.

14. Cannot operate Time Shifted Recording. (PVR only)

- TSR may not be available during recording. Wait until the recording is finished.
- Delete unnecessary programmes and make space for new recording.

15. Cannot playback. (PVR only)

- To playback the recorded file of a scrambled channel, use the Smartcard. In case it has been a long time since you last recorded, this may not work. Contact the product distributor.
- The signal during recording may be weak or the hard disk too full.

16. Cannot change channels while recording. (PVR only)

- Certain channels may not be changed due to restriction of the tuner or connection type.

HUMAX Customer Support

Information concerning troubleshooting, software upgrade and product support is provided in the following website. Should your product require warranty service, please contact the customer service center of which telephone number is on the website.

Middle East (Dubai, UAE)	Tel:	+971 4 359 2323
	Opening Hours (Closed on Fri):	Sat-Wed: 09:00-18:00 Thu: 09:00-14:00
	E-mail:	callcenterME@humaxdigital.com
	Website:	http://www.humaxdigital.com/me/support
	Language:	Arabic / English

Note: For hardware repair, please visit our website.

Error Messages

Error messages	Possible causes	What to do
No or bad signal [Satellite]	The satellite dish is not pointing at the satellite.	Adjust the dish alignment.
	Signal is too weak.	Increase the LNB voltage or connect a signal amplifier.
	Satellite dish is too small.	Change to a larger dish.
	Problem with LNB	Change the LNB.
	Wrong antenna setting	Set the antenna correctly.
No or bad signal [Cable]	The cable is not connected.	Make sure the cable is connected correctly.
	The cable may be damaged or defective.	Replace the cable.
	The channel is not broadcasting.	Replace the cable.
No or bad signal [Terrestrial]	The aerial is not pointing correctly.	Adjust the aerial. Check the cable from the aerial. If you cannot resolve the problem, request a professional to test your aerial installation.
The channel is scrambled or not available.	The channel has a signal but no audio or video.	Check if the channel is currently on air.
	The channel has been deleted by the broadcasting company.	Check if the channel is currently on air.
	The channel is for data broadcasting.	Remove the channel from the channel list and check for new transponder details.
The audio is not available.	The channel has a video signal but no audio.	Press the audio button to confirm that the channel has audio options.

Error messages	Possible causes	What to do
No access	No access	Make sure you have a subscription to the channel.
	No authorisation	If the product has been in standby or power off for a long time, please wait for authorisation. It may take up to 60 minutes.
No card inserted	Smartcard is not inserted.	Insert the Smartcard.
Incorrect card	Wrong Smartcard is inserted.	Insert the correct Smartcard.
	Smartcard is not inserted correctly.	Remove the Smartcard and reinsert it.
	Smartcard is damaged.	Contact your Smartcard retailer or channel broadcaster and ask for replacement.
CI-Module not installed	CI-Module not installed CI-Module is not inserted.	Insert the CI-Module.
	CI-Module is not inserted correctly.	Remove the CI-Module and reinsert it.
	CI-Module is not recognised.	Insert another CI-Module to check if the current one is working.
Invalid CI-Module	Wrong CI-Module	Insert the correct CI-Module.
	CI-Module is damaged.	Replace the CI-Module.
The antenna cable is short-circuited. [Satellite]	LNB cable is short.	Replace the LNB cable.
	LNB is internally short.	Replace the LNB.
	Alien substance is inserted into the LNB IN port. The port may be damaged.	Remove the alien substance and contact the service centre if the port is damaged.

Glossary

CVBS (Composite Video Baseband Signal)

A technology for transmitting video signals via a cable. Mixes luminance (brightness) and the chrominance (colour) signals together.

DiSEqC (Digital Satellite Equipment Control)

A DiSEqC compatible receiver relies on a switching box which detects the 22kHz tone pulsing rapidly on and off. In this way, a certain receiver can control numerous LNBs through a DiSEqC switching box.

Dolby Digital

An encoding system that digitally compresses up to 5.1 discrete channels of audio (left front, centre, right front, left surround, right surround) into a single Bitstream. A low frequency effect (LFE) channel is included providing the sound needed for special effects.

DVB (Digital Video Broadcasting)

A set of standards that define digital broadcasts using satellite, cable or terrestrial systems.

EPG (Electronic Programme Guide)

An electronic equivalent to a printed television listings magazine. It is an application used with digital set-top boxes and digital television sets to list current and scheduled programmes that are or will be available on each channel, including a short summary or commentary for each programme. The information supplied in the EPG is sent and updated by the channel broadcaster.

FEC (Forward Error Correction)

A technique for error control of data transmission.

Frequency

The property of a signal measured in cycles per second (=Hz).

FTA (Free- To-Air)

An unscrambled broadcaster allowing customers to view channels or services without paying any subscription.

HDMI (High-Definition Multimedia Interface)

An all-digital audio/video interface that supports standard, enhanced, or high-definition video, plus multi-channel digital audio on a single cable. It transmits all ATSC HDTV standards and supports 8-channel digital audio.

LNB (Low Noise Block)

A device that is mounted on an arm facing your satellite dish, focusing on satellite signals. A LNB converts signals received from satellite to a lower frequency and sends them to a satellite receiver via coaxial cable.

OTA (Over the Air)

A standard for the transmission of software for equipment, through a broadcast system. Manufacturers reserve the right for deciding the release of the software for their products.

Polarisation

The direction of the electrical and magnetic fields of a signal. Satellites use both vertical and horizontal polarisation, meaning that a frequency can be used twice.

QPSK (Quadrature Phase Shift Keying)

Digital modulation technique in which the carrier phase can have one of four possible values.

RF (Radio Frequency)

Television signals are modulated onto RF signals and are then demodulated by the tuner of your TV or STBs.

RGB (Red – Green – Blue)

A technology for transmitting video signals via a cable. RGB is a system to represent red, green, and blue colours on a TV or monitor display. Red, green, and blue can be combined in various proportions to obtain any colour.

Smartcard

A credit card sized card that contains updateable chip memory. It is used to access Pay TV (encrypted) channels or services.

S/PDIF (Sony/Philips Digital Interface format)

A standard format for the transfer of digital audio signals. It allows the transfer of digital audio between two devices without any conversion to and from analogue, which could degrade the signal quality.

Transponder

A satellite is divided up in parts called transponders. A transponder is one distribution section of the satellite. Each transponder can be used for distribution of several channels or services.

Open Source Software Notice

HUMAX products use certain open source operating system software distributed pursuant to GNU GENERAL PUBLIC License version 2 and GNU LESSER GENERAL LICENSE version 2.1 each as defined and published by the Free Software Foundation, Inc. The following GPL and LGPL software source codes used in this product can be provided and this offer is valid for up to three years from the date of original download of the software or purchase of product containing such software. Please contact us at gnu@humaxmagical.com.

GPL Software

linux
busybox
tinyftp
avinfo
netpcnt
e2fsprogs

This package, the ext2 filesystem utilities, are made available under the GNU GPL license version 2, with the exception of the lib/ext2fs and lib/e2p libraries, which are made available under the GNU Library General Public License version 2, the lib/uuid library which is made available under a BSD-style license and the lib/et and lib/s libraries which are made available under an MIT-style license.

LGPL Software

libc
libffi
libidn
libpng

This software uses libraries from the Ffmpeg project under the LGPLv2.1

FreeType License (FTL) Software

freetype

Portions of this software are copyright © <2007> The FreeType Project (www.freetype.org).

All rights reserved.

Use, modification and redistribution of the Open Source Software is governed by the terms and conditions of the applicable Open Source License. The GNU General Public License (GPL) v2 is shown below.

The GNU General Public License (GPL) Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is licensed under the Lesser General Public License instead.) You can apply it to your programs, too. When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you gave you. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two legal mechanisms: (1) copyright the software, and (2) offer you the license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that anyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations. Finally, any free program should be controlled by the community that uses it, not by those who write it. For this reason, we wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed to everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This license applies to any program or other work which contains a notice in its source code stating it is licensed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law; that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distributing and modification are not covered by this license; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if it's contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty, keep intact all the notices that refer to this license and to the absence of any warranty, and give any other recipients of the Program a copy of this license along with the Program. You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this license.

c) If you modified the program normally reads commands interactively when you start it, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this license. (Exception: If the program is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this license, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this license, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of work that is based on the Program. In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this license.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or

c) Accompany it with the written offer, valid for at least three years, to distribute a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or

d) Accompany it with the written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or

to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this license. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this license. However, parties who have received copies, or rights, from you under this license will not have their licenses terminated so long as such parties remain in full compliance. 5. You are not required to accept this license, since you have not signed it. However, no other arrangement will permit you to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this license. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this license to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restriction on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this license.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this license, they do not excuse you from the conditions of this license. If you cannot distribute the Program as a result of such a judgment, you may not distribute the Program at all. For example, if a patent holder seeks to bring suit against the distributor of copies of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this license would be to refrain entirely from distributing the Program. If your distribution was otherwise to be compliant with the conditions of this license, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances. It is not the purpose of this section to protect your patent from others who might sue you for claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through this system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other relation and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this license.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this license may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this license incorporates the limitation as if written in the body of this license.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this license which appears to be an "older" version, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of the license, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, you may do so by writing permission for software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our policy is to allow this only in the rare case of closing the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR ANY OTHER PARTY TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY

WHOM MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (EVEN IF THE PROGRAM IS LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF YOU HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms. To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty, and each file should have at least the "copyright" line and a pointer to where the full notice is found.

One line to give the program's name and a brief idea of what it does:

Copyright (C) yyyy, name of author. This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the license, or (at your option) any later version. This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details. You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA. Also add the text below to the bottom of each source file to give the program its name and to give more information about how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69 Copyright (C) year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even have been something like 'show patches' or 'show conditions'. You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoodyene, Inc., hereby disclaims all copyright interest in the program 'Gnomovision' (which makes passes at compilers) written by James Hacker. signature of T. Coon, 1 April 1989

T. Coon, President of Yoodyene, Inc.

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

GNU Lesser General Public License (LGPL) Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the second version of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users.

There is, however, a problem. Licenses that give the free user the freedom of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software or use pieces of it in new free programs; and that you know you can do these things. To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that you gave you. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two legal mechanisms: (1) copyright the software, and (2) offer you the license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that anyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations. Finally, any free program should be controlled by the community that uses it, not by those who write it. For this reason, we wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed to everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights. We protect your rights with a two-step method: (1) we copy each title and add the library's license to you this license gives you legal permission to copy, distribute and/or modify the library. To protect each copyright, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages for libraries. The Lesser license is more permissive than the GPL, so it may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. Without this provision, the free library would be the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser license. However, the Lesser license is not intended to be a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the library in non-free programs enables the library to be used by the rest of the whole GNU operating system, as well as its variant, the GNU/Linux operating system. Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of the library has the freedom with the Library has the freedom and the wherewithal to run that program using a modified version of the Library. The precise terms and conditions for copying and distribution are given in the next section. In particular, the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the

This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this License. (The copyright holder's name and other information may be addressed as you wish.) A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executable programs. (The linking may be done by hand or by a computer program, which has been distributed under these terms.) A "work based on the Library" means either the Library or any derivative work under copyright law; that is to say, a work containing the Library or a portion of it, either verbatim or with additions and/or deletions; or any such work translated into a different language. Hereinafter, translation is included without limitation in the term "modification." "Source code" for a work means the preferred form for the work for making modifications to it. For a library, complete source code and documentation is the preferred form. For a program, the preferred form is the text of the source code and the interface definition files, plus the scripts used to control compilation and installation of the library. Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. From the moment you receive the code, you are authorized to copy and distribute it, subject to the following restrictions. Your program is covered only if its contents constitute a work based on the Library (independent of the use of the library in a tool for writing it). Whether that is true depends on what the Library does and what the

2. You may modify your copy or copies of the Library or any portion of it.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License. However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the Library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications. You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License.

For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library. If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances. It is not the purpose of this

Yoyodyne, Inc., hereby disclaims all copyright interest in the library 'Frob' (a library for tweaking knobs) written by James Random Hacker.
signature of Ty Coon, 1 April 1990



Warranty Certificate

IMPORTANT:

Keep this Certificate together with the Original invoice or receipt in a safe place and show them to the retailer or place of purchase whenever a warranty repair is necessary.

• **Model No.:** _____

• **Serial No.:** _____

• **Date of Purchase:** _____

• **Dealer's Signature:** _____

• **Customer's Signature:** _____

HUMAX thanks you for your recent HUMAX product purchase.

For your benefit, we recommend that you record your serial number, found on the product, and other purchase information on this card and keep it with your personal records, along with proof of purchase. This information will allow us to better serve your needs.

■ WARRANTY CONDITIONS

Keep this Certificate together with the original invoice or receipt in a safe place and show them to the retailer or place of purchase whenever a warranty repair is necessary.

■ HUMAX CONSUMER WARRANTY

HUMAX warrants this product to be free of defects in materials and workmanship, subject to the conditions set forth overleaf.

■ CONDITIONS

1. The HUMAX Warranty is valid for a period of one year from the date of first purchase.
2. In the event that this product fails to function properly during the warranty period, the retailer or distributor will make this product capable of operating for the purpose of which it was designed, without charging for labour and parts.
3. This warranty will be honoured only if the Warranty Certificate has been duly completed by the purchaser and is presented to the retailer with the original invoice or receipt.
4. This warranty does not cover shipping or transportation charges from you to us.
5. The obligations of the distributor are limited to the repair of defect parts. Costs and risks of transport to the retailer as well as removal and installation of the product, and any other costs directly or indirectly related to its repair, are not covered by the warranty.
6. All warranty repairs performed by non-authorized repair shops will not be reimbursed and if such repairs damage this product such damage will not be covered by this warranty.
7. This warranty is not applicable in cases other than defects in materials or workmanship and, in particular, does not cover:
 - a. periodic check-ups, adjustments, maintenance or conversions as well as replacement of parts due to normal wear and tear;
 - b. damage caused by accidents, negligence, modifications, use of non-HUMAX parts, improper use, installation or package;
 - c. damage caused by lightning, water, fire, acts of war, public disturbances, incorrect mains voltages, incorrect ventilation or any other cause beyond the control of the distributor;
 - d. products where the label bearing the serial number has been removed, defaced or is illegible.
8. This warranty is offered to any person who has legally obtained possession of this product within the warranty period.
9. HUMAX's maximum liability shall not exceed the actual purchase price paid by you for the product. In no event shall HUMAX be liable for special, incidental, consequential or indirect damages.

Middle East (Dubai, UAE)

Tel: +971 4 359 2323
Opening Hours: Sat – Wed : 9:00 – 18:00
(Closed on Fri) Thu : 9:00 – 14:00
E-mail: callcenterME@humaxdigital.com
Website: <http://www.humaxdigital.com/me/support>
Language: Arabic/English

Certificat de garantie

IMPORTANT !

Conservez le certificat conjointement avec la facture ou le reçu original dans un endroit sûr. Présentez-les à votre revendeur ou à votre lieu d'achat dès que votre produit nécessite une réparation sous garantie.

• **N° de modèle :** _____

• **N° de série :** _____

• **Date d'achat :** _____

• **Signature du revendeur :** _____

• **Signature du client :** _____

HUMAX vous remercie pour l'achat récent d'un de nos produits.

Pour en tirer pleinement profit, nous vous recommandons de consigner sur cette carte le numéro de série figurant sur le produit ainsi que d'autres informations concernant votre



Moyen-Orient (Dubai, EAU)

Tél :	+971 4 359 2323
Opening Hours:	Samedi - Mercredi : 9:00 – 18:00
(fermé le vendredi)	Judi : 9:00 – 14:00
E-mail :	callcenterME@humaxdigital.com
Website:	http://www.humaxdigital.com/me/support
Language:	Arabe/anglais

achat et de la conserver avec vos données personnelles, conjointement avec votre preuve d'achat. Ces informations nous permettront de mieux répondre à vos attentes.

■ CONDITIONS DE GARANTIE

Conservez le certificat conjointement avec la facture ou le reçu original dans un endroit sûr. Présentez-les à votre revendeur ou à votre lieu d'achat dès que votre produit nécessite une réparation sous garantie.

■ GARANTIE CLIENT HUMAX

HUMAX garantit que ce produit ne présente aucun défaut au niveau des matériaux et de la fabrication, conformément aux conditions mentionnées au verso.

■ CONDITIONS

1. La garantie HUMAX est valide pour une période d'un an, à compter de la date de l'achat initial.
2. Dans l'éventualité où ce produit ne fonctionnerait pas correctement au cours de la période de garantie, le revendeur ou le fournisseur local s'engage à le faire fonctionner conformément à la finalité pour laquelle il a été conçu, sans facturer de frais supplémentaires pour la main-d'œuvre et les pièces.
3. La présente garantie ne s'applique que si le certificat de garantie a été dûment complété par l'acheteur et que ce certificat est présenté au revendeur conjointement avec la facture ou le reçu original.
4. La présente garantie ne couvre pas les frais d'expédition ou de transport entre l'acheteur et HUMAX.
5. Les obligations du revendeur se limitent à la réparation des pièces défectueuses. La présente garantie ne couvre pas les coûts et les risques liés au transport à destination du revendeur, ceux associés à l'installation et à l'enlèvement du produit ainsi que tout autre coût directement ou indirectement lié à sa réparation.
6. Les coûts liés aux réparations sous garantie effectuées par un atelier de réparation non autorisé ne seront pas remboursés. En outre, si le produit est endommagé lors de telles réparations, les dégâts causés ne seront pas couverts par la présente garantie.
7. La présente garantie ne s'applique pas aux cas autres que les défauts de matériaux ou de main-d'œuvre et ne couvre pas, en particulier :
 - a. les vérifications périodiques, les réglages, la maintenance ou les transformations ainsi que le remplacement de pièces en raison de l'usure normale ;
 - b. les dégâts causés par des accidents, par négligence, par l'apport de modifications, par l'utilisation de pièces non HUMAX, par une utilisation incorrecte ou lors de l'installation ou l'emballage ;
 - c. les dégâts causés par la foudre, l'eau, le feu, les faits de guerre, les troubles publics, des tensions de secteur incorrectes, une mauvaise ventilation ou toute autre cause indépendante de la volonté du revendeur ;
 - d. les produits dont l'étiquette portant le numéro de série est illisible, a été enlevée ou abîmée.
8. La présente garantie est offerte à toute personne qui est entrée en possession de ce produit légalement au cours de la période de garantie.
9. La responsabilité maximale d'HUMAX ne peut pas dépasser le prix d'achat que vous avez payé pour acquérir le produit. En aucun cas HUMAX ne peut être tenu pour responsable des dommages-intérêts particuliers, accessoires, secondaires ou indirects.

